


SEANAPTIC 1.0

- Parametric ship design for Rhino -




Seanaptic 1.0 Installation Guide


Rhinoceros3D version 5 must be installed on your machine prior to Seanaptic installation.

To install Seanaptic 1.0 version, please follow the next steps:


- Run *Seanaptic1.0.exe* installation file.
- The *Setup – Seanaptic* window will appear. Select **Next >** to continue the installation.




- To continue, click **Next>** button. If you would like to select a different folder for the installation, click **Browse** button.




- Click **Install** button to proceed with the installation:




- Click **Finish**:




- Open **Rhinoceros 5 (32 or 64-bit)** and type *SeanapticCreateProject* in the Command bar:




- Press **Enter** from the keyboard. Seanaptic will try to connect to the license server to start the activation. *SEANAPTIC Product Registration* window will appear:



- Select **Configure as a trial** and then press **OK** button:




- Check **Don't show this message again**. Then click **OK** button:



- Fill in the following credentials: **Company Name***, **Contact Name***, **Country*** and **Email Address***.

Then press **OK**.

- An email from CopyMinder Verification will be sent to your address to confirm the registration, so press **OK** to close this window.



- Check your email address and click the link in the email to activate the Seanaptic trial. The CopyMinder website will open and confirm the activation of the license.



- Go back to Rhino and type again in the Rhino Command bar: *SeanapticCreateProject* and press **Enter**. Seanaptic 1.0 window will pop-up, and the date when the trial version will expire is displayed in the Rhino Command bar:

